


5000 RIDE ON SCRAPER

Weight(kg)	Height(cm)	Width(cm)	Length(cm)	Hand arm vibration	Noise(db)
907.2	121	62	160	10 m/s2	95



EACH TIME BEFORE USING MACHINE

This machine should only ever be used by a trained and competent person.

Upon acceptance, please check the machine has in no way been damaged in transit and works, and each time prior to use. If you have any questions or doubts, please contact us, also in the event of breakdown or damage. The machine's weights can be dismantled with the two screws on top of each weight.

Please check that all safety mechanisms and switches are intact and working correctly.

Please make sure that the floor you're about to prep is clear of all foreign objects that could cause damage to the machine or operator. This must be completed every time before using the machine.

Please check every day that all belts, bearings and moving parts are in good condition, this could lead to breakages or even injury.

USING THE MACHINE

Turn the switch on using the key or button to the right-hand side of the Seat (note there is a dead man's switch on the seat, you will need to be sat on the machine to start. Check that the emergency stop works, reversing beacon and reversing alarm each time before use. You will have four levers on the machine. The two big ones control each of the back wheels. Push for forwards, pull for reverse. The two smaller levers alter the front. The right sided pulls the front holder up and down. The left handle alters the pitch in which the machine operates. When the machine is delivered it will arrive with transport wheels to remove these pull both of the smaller levers fully so that the wheels are off the ground. Pull the pin out of the wheels shaft and pull the wheels out. Now insert the blade and blade holder, fastening with the lunch pin from the wheels. To scrape the floor alter the pitch to the suitable angle and pitch using the two smaller levers. Use the two larger levers to move the machine forwards.

AFTER USING AND PRIOR TO RETURNING THE MACHINE

Please ensure that the machine is unplugged and kept in a safe place.

An off-hire will never be arranged at the beginning of the hire period. Please call the office and arrange collection as soon as you know when the machine/machines will no longer be required.

Please make sure the machine is returned in a fit and clean state to avoid charges. Please make sure that the screws holding the weights together are not lost.

If multiple machines are being collected, please have them placed neatly together, ready to collect because time may be charged if we have to search or wait for equipment. Items not available for collection will remain on hire and additional collection charges will apply. If the machine is to be collected by a carrier, please ensure it's strapped securely to the pallet using the straps that it arrived with and is left somewhere obvious and preferably arrange for someone to be responsible for supervising the collection.

All information above is provided for guideline purposes only. For more accurate and reliable information please refer to the manufacturer.

Multi-Hire Power Tools
Warrington
www.multi-hire.co.uk
01925 653633

