

Commander stripper

Weight(kg)	Height(m)	Width(cm)	Length(m)	Hand arm vibration	Noise(db)
197	1m	36cm	78cm	10 m/s ²	



EACH TIME BEFORE USING MACHINE

This machine should only ever be used by a trained and competent person.

Upon acceptance, please check the machine has in no way been damaged in transit and works, and each time prior to use. If you have any questions or doubts, please contact us, also in the event of breakdown or damage. The machine's weights can be dismantled with the two screws on top of each weight.

Please check that all safety mechanisms and switches are intact and working correctly.

Please make sure that the floor you're about to prep is clear of all foreign objects that could cause damage to the machine or operator. This must be completed every time before using the machine.

Please check every day that all belts, bearings and moving parts are in good condition, this could lead to breakages or even injury.

USING THE MACHINE

Make sure that the blade is still intact and the bolts are securely tight. Turn the switch on using the switch at the top of the handle. Use the hydraulic handle (the two arms pointing out from the handle and push forward) to use the machine's hydraulic self-propel motion. When you are stood at the machine in the usage position there is a black circular switch closest to you. THIS IS THE SPEED CONTROL! This will make the machine operate in backwards mode only if switch is the wrong direction. Do not lever the machine as this could cause damage. To turn the machine off push the switch back off. Keep fingers away from the blade at all times. The success of this machine is choosing the right blade. Our default blade is the straight blade suitable for ripping up most carpets and carpet tiles but on request we can supply U shaped blades for tearing vinyl and small blades for very stubborn surfaces.

If the machine is struggling to take up the surface, try the following –

- The weights on the side of the machine are adjustable, push them forward to increase the weight on top of the blade or backwards if the rear wheels are not gripping.
- Try cutting the surface to be removed into strips using a sharp utility knife.
- Use a narrow blade which will encounter less friction resistance.
- Turn the blade over so that it either digs in to get under the surface or conversely, to slide and glide over the surface if it is digging into the surface and getting stuck.
-

AFTER USING AND PRIOR TO RETURNING THE MACHINE

Please ensure that the machine is unplugged and kept in a safe place.

An off-hire will never be arranged at the beginning of the hire period. Please call the office and arrange collection as soon as you know when the machine/machines will no longer be required.

Please make sure the machine is returned in a fit and clean state to avoid charges. Please make sure that the screws holding the weights together are not lost.

If multiple machines are being collected, please have them placed neatly together, ready to collect because time may be charged if we have to search or wait for equipment. Items not available for collection will remain on hire and additional collection charges will apply. If the machine is to be collected by a carrier, please ensure it's strapped securely to the pallet using the straps that it arrived with and is left somewhere obvious and preferably arrange for someone to be responsible for supervising the collection.

All information above is provided for guideline purposes only. For more accurate and reliable information please refer to the manufacturer.

Multi-Hire Power Tools

Warrington

www.multi-hire.co.uk

01925 653633