

## **Triple head grinders 415v**

Weight(kg)	Height(mm)	Width(mm)	Length(m)	Hand arm vibration	Noise(db)
147	1102	555	973	unrestricted	



### **EACH TIME BEFORE USING MACHINE**

### **EACH TIME BEFORE USING MACHINE**

This machine should only ever be used by a trained and competent person.

Upon acceptance, please check the machine has in no way been damaged in transit and works, and each time prior to use. If you have any questions or doubts, please contact us, also in the event of breakdown or damage.

Please check that all safety mechanisms and switches are intact and working correctly.

Please make sure that the floor you are about to prep is clear of all foreign objects that could cause damage to the machine or operator. This must be completed every time before using the machine. The machine must only be used and moved on level surfaces. There is a risk of crushing if the machine starts to roll. Beforehand perform a scan of the surface to look out for bolts and studs, preferably using a metal detector.

Please check every day that all belts, bearings and moving parts are in good condition because this could lead to something breaking and causing injury.

### **USING THE MACHINE**

Please ensure that the shoes have been inserted/screwed onto the tool holders properly. Please ensure none can fly off which could cause damage or injury. To start the machine, make sure the emergency stop is twisted out and turn the dial over to 1. The green light should now appear if the machine has one. Next push go whilst the head is on the floor. The machine should now be working. Depending on the type of machine it will also have a speed control switch. You will need to turn this until you have the desired speed at which you wish to grind. To stop the machine, use the power button from No. 1 to No. 0.

### **AFTER USING AND PRIOR TO RETURNING THE MACHINE**

Please ensure that the machine is unplugged and kept in a safe place.

An off-hire will never be arranged at the beginning of the hire period. Please call the office and arrange collection as soon as you know when the machine/machines will no longer be required.

Please make sure the machine is returned in a fit and clean state to avoid charges.

If multiple machines are being collected, please have them placed neatly together, ready to collect because time may be charged if we have to search or wait for equipment. Items not available for collection will remain on hire and additional collection charges will apply. If the machine is to be collected by a carrier, please ensure it's strapped securely to the pallet using the straps that it arrived with and is left somewhere obvious and preferably arrange for someone to be responsible for supervising the collection.

All information above is provided for guideline purposes only. For more accurate and reliable information please refer to the manufacturer.

Multi-Hire Power Tools  
Warrington  
[www.multi-hire.co.uk](http://www.multi-hire.co.uk)  
01925 653633